

SQ576



Jumper Settings

CPU speed/voltage support may be dependant upon motherboard/BIOS revision
CPU Type and Selection

Intel CPU Setting	JP6	JP7	JP8	JP1
90MHz				
100MHz				
120MHz				
133MHz				
150MHz				
166MHz				
180MHz				
200MHz				
233MHz				

Cyrix 6X86 Setting	JP6	JP7	JP8	JP1
110MHz(=P133+)				
120MHz(=P150+)				
133MHz(=P166+)				

AMD K5 CPU Setting	JP6	JP7	JP8	JP1
PR100				
PR120				
PR133				
PR150				
PR166				
PR200				

AMD K6 CPU Setting	JP6	JP7	JP8	JP1
PR2-166				
PR2-200				
PR2-233	NOT SUPPORTED! Please use our SQ575 for this CPU.			

CPU Voltage Selection

Intel/AMD/Cyrix Selection	JP10	JP5	JP4
Intel P54C AMD K5 Cyrix 6X86 (3.4V-3.6V)			
P54C STD (3.135-3.6V)			
AMD K6 (2.9V)			
P55C (V _{io} =3.38V) (V _{core} =2.8V)			

* Product specifications subject to change without notice.